

Document Number	Model	Serial Number Range	Part Number
12-80006	AB-100 Plastic Winder	All Units	85-B0027

⚠ WARNING

Before making repairs or adjustments set the parking brake, turn off the engine, and remove the ignition key.
Always disconnect the negative battery cable from the battery when working with electrical components. Always work in a manner that does not put safety at risk!

⚠ WARNING


Safety glasses must be worn during installation. Ear (hearing) protection must be worn when using air or power tools.

Installation Notes: Right and left hand orientation referred to in these instructions is determined as if facing forward from the operator station.


Installation Time (estimated) 1 hour

Tools Required: 7/16" wrench, 7/16" socket, 9/16" wrench, 9/16" socket, 3/4" wrench, 3/4" socket, Torque wrench, Ratchet

- Remove the tension from the belt by adjusting the tensioner (A) to the lowest position (B).




- Remove the seven 1/4" bolts (D) and the seven 1/4" flat washers around the outside perimeter of the pulley cover.



- Remove the pulley cover (C).
- Remove the belt from the pulleys.


- To remove the tensioner pulley (F) remove the 3/8" bolt (E), secured in place by the 3/8" locking flange nut.




- Remove the tensioner assembly by removing the 1/2" locking nut (G) that secures the tensioner to the top cover.




- Remove the 1/2" lock nut (J), 1/2" bolt (H), and 1/2" washer (I) from the tensioner assembly.



- Remove the bushings (K) from the tensioner assembly.




- Install the new bushings into the tensioner assembly.
- Install the 1/2" bolt with the flat washer installed through the tensioner assembly as shown below




- Secure the 1/2" bolt in place with a 1/2" lock nut (L). Tighten the nut down until it is snug and then loosen the nut one thread. The assembly should rotate freely on the 1/2" bolt.


- Position tensioner assembly in the top cover. Insert the tensioner mounting bolt through the upper mounting hole (M).



- Ensure that the torsion spring adjustment handle (N) is placed through the top cover (O).




- Secure the tensioner in place with the 1/2" locking flange nut. Torque the flange nut to 85 ft-lbs (115 Nm).
- Place a 3/8" washer on the 3/8" bolt, followed by the tensioner pulley and another 3/8" washer as shown below.




16. Install the pulley onto the tensioner pulley mount in the center mounting hole (P).

22. Reinstall the pulley cover. Torque the 1/4" bolts to 100 in-lbs (11 Nm).



- 17. Secure the tensioner pulley in place using a 3/8" locking flange nut.
- 18. Torque the 3/8" bolt to 35 ft-lbs (47 Nm).
- 19. Ensure that the tensioner pulley is in line with the idler pulley and the reel drive pulley.
- 20. Install the belt, by routing the belt around the pulleys as shown below.

	Attention
<p>NOTE: The V portion of the belt must be on the plastic winder reel drive pulley (Q).</p>	



21. Set the belt tension as required by adjusting the tension adjustment lever.