



1- Bolted the screw N°1 and the nuts, do not forget to place the washer N°2 between the welded part and the chassis.

2- Bolted the screws N°3 and the nuts into the correct holes.

3- Place the axis N°4 into the correct holes the height cutting is chosen here. Do not forget to secure the axis N°4 with the pin N°5

4- This 3 operation had to be done in both side.

5- Dispose the tube N°6 and the threaded bar N°7 Into the bearing N°8.

6- Place the washer N°9 and screw the nuts N°10 into the threaded bar N°7

7- This 2 operations had to be done in both side.