

Document Number	Kit Number / Part Number	Model	Serial Number Range
12-70072	AV-9047	Super E	All Units

**⚠ WARNING**

Before making repairs or adjustments set the parking brake and turn off and remove ignition key.  
Always disconnect all batteries when working with electrical components. Always work in a manner that does not put safety at risk!

**⚠ WARNING**

Safety glasses must be worn during installation. Ear (hearing) protection must be worn when using air or power tools.

**Installation Notes:** Right and left hand orientation referred to in these instructions is determined as if facing forward from the operator station.

**Installation Time (estimated)** 10 Minutes

**Tools Required:** 3/4" Wrench, 3/4" Socket and Impact Driver

Kit Contents		
Part #	Description	Qty.
90-0812	Bolt, 1/2-13 USS x 1 1/2	3
95-08	Washer, Flat 1/2 SAE	3
99-SF08	Nut, SRF 1/2-13 USS	3
--	Top Link Mast Assembly	1

1. Open the hardware pack and pull out the three 90-0812 Bolts, 95-08 Washers and 99-SF08 Nuts. Pass the bolts through the washers.



2. Hold the Top Link Mast Assembly up to the inside of the RH side mounting bracket on the Tilmor Toolbar and pass the bolts through the three holes. Start the nuts on the bolts.



3. Use the impact driver with the 3/4" socket to tighten the three bolts. Nuts should tighten automatically when bolt is turned, but if they are not tightening then use a 3/4" wrench to hold them as the bolts are tightened with the impact.



**Assembly Complete**