


PLANTOIR À POIREAUX LEEK PLANTER

T000166 / T000800



Ce planteur à poireaux de Terrateck a été spécifiquement conçu pour le repiquage des plans de poireaux. Ce modèle robuste, fabriqué en acier, est équipé de deux manches en bois.

Les planteurs creusent des trous larges de diamètre 25mm et profonds de 220mm.

1. Travailler debout, en poussant avec le pied sur la barre métallique

2. Faire quelques mouvement avant-arrière pour libérer les planteurs

3. Tirer sur les manches pour ressortir l'outil

La distance entre les rangs est réglable entre 80 et 180mm grâce aux jauge latérales ; en utilisant ces repères vous aurez une plantation homogène.

L'utilisation de cet outil sera facilitée dans les terres meubles et souples, préalablement travaillées, affinées et humidifiées car le poireau est une plante exigeante qui se plaît en terre profonde et meuble, fraîche et substantielle, fortement enrichie au fumier l'année précédente.

Cet outil est sous garantie. Celle-ci ne s'applique pas sur les manches mais uniquement sur les parties métalliques sauf consommables (visserie, ressort, autre) et dans le cadre d'une utilisation normale.

This Terrateck's planter has been specifically developed for transplanting leek plants. Made of stainless steel, this sturdy tool is equipped with two wooden handles.

The planter digs large holes 25mm diameter and 220mm deep.

1. Work in an upright position while pushing down with your foot on the iron bar.

2. Gently move the handles back and forth to release the planter's rods

3. Pull out the planter by lifting the handles

In-row spacing can be adjusted between 80 and 180 mm thanks to the rails on the sides; The use of these markers will allow homogeneous planting.

The use of this tool suits soft and elastic soils that have been previously tilled, refined and moistened, since leek is a demanding plant that loves deep soft, fresh and consistent soils rich in nutrients.

This tool is covered under warranty. However, this does not apply to handles, but only to metal parts, with the exception for consumables (screws, springs, other) and under ordinary use.



CONTACTEZ-NOUS

Tel : +33(0) 3 74 05 10 10
Mail : contact@terrateck.com
www.terrateck.com